

Алматы (7273)495-231
 Ангарск (3955)60-70-56
 Архангельск (8182)63-90-72
 Астрахань (8512)99-46-04
 Барнаул (3852)73-04-60
 Белгород (4722)40-23-64
 Благовещенск (4162)22-76-07
 Брянск (4832)59-03-52
 Владивосток (423)249-28-31
 Владикавказ (8672)28-90-48
 Владимир (4922)49-43-18
 Волгоград (844)278-03-48
 Вологда (8172)26-41-59
 Воронеж (473)204-51-73
 Екатеринбург (343)384-55-89

Иваново (4932)77-34-06
 Ижевск (3412)26-03-58
 Иркутск (395)279-98-46
 Казань (843)206-01-48
 Калининград (4012)72-03-81
 Калуга (4842)92-23-67
 Кемерово (3842)65-04-62
 Киров (8332)68-02-04
 Коломна (4966)23-41-49
 Кострома (4942)77-07-48
 Краснодар (861)203-40-90
 Красноярск (391)204-63-61
 Курск (4712)77-13-04
 Курган (3522)50-90-47
 Липецк (4742)52-20-81

Магнитогорск (3519)55-03-13
 Москва (495)268-04-70
 Мурманск (8152)59-64-93
 Набережные Челны (8552)20-53-41
 Нижний Новгород (831)429-08-12
 Новокузнецк (3843)20-46-81
 Ноябрьск (3496)41-32-12
 Новосибирск (383)227-86-73
 Омск (3812)21-46-40
 Орел (4862)44-53-42
 Оренбург (3532)37-68-04
 Пенза (8412)22-31-16
 Петрозаводск (8142)55-98-37
 Псков (8112)59-10-37
 Пермь (342)205-81-47

Ростов-на-Дону (863)308-18-15
 Рязань (4912)46-61-64
 Самара (846)206-03-16
 Санкт-Петербург (812)309-46-40
 Саратов (845)249-38-78
 Севастополь (8692)22-31-93
 Саранск (8342)22-96-24
 Симферополь (3652)67-13-56
 Смоленск (4812)29-41-54
 Сочи (862)225-72-31
 Ставрополь (8652)20-65-13
 Сургут (3462)77-98-35
 Сыктывкар (8212)25-95-17
 Тамбов (4752)50-40-97
 Тверь (4822)63-31-35

Тольятти (8482)63-91-07
 Томск (3822)98-41-53
 Тула (4872)33-79-87
 Тюмень (3452)66-21-18
 Ульяновск (8422)24-23-59
 Улан-Удэ (3012)59-97-51
 Уфа (347)229-48-12
 Хабаровск (4212)92-98-04
 Чебоксары (8352)28-53-07
 Челябинск (351)202-03-61
 Череповец (8202)49-02-64
 Чита (3022)38-34-83
 Якутск (4112)23-90-97
 Ярославль (4852)69-52-93

Россия +7(495)268-04-70

Казахстан +7(7172)727-132

Киргизия +996(312)96-26-47

<https://pira.nt-rt.ru> || par@nt-rt.ru

- Made of cast iron
- Piracold® refrigeration system
- 7 guides
- Front ash drawer
- Built-in firebreak inside the oven
- Analog temperature display
- Exhaust switch to control air flow
- Built-in grease collector

PIRA

120 SILVER

PIRA 120 SILVER SD

REF.	120.106
------	---------



PIRA 120 SILVER ED


REF.	120.107
------	---------




TECHNICAL INFORMATION

Average production	150 Kg/h	Capacity in GN trays	3xGN 1/1
Maximum charcoal capacity	6 Kg	Smoke Outlet	210mm
Maximum charcoal consumption	7 Kg per service	Net weight SD	360 Kg
Fire up time	40 min.	Net weight ED	391 Kg
Cooking temperature	180°C to 350°C	Power equivalence	8.0 KW

DIMENSIONS PIRA 120 SILVER SD



DIMENSIONS PIRA 120 SILVER ED



INCLUDED ACCESSORIES

REF.	DESCRIPTION
950.004	Meat Tongs TOP 400 mm
950.008	Poker
900.120	Rod Grill 120 (1060x625)
904.012	Front Inox Table 40 cm 120 ED



ROD GRILL



MEAT TONGS TOP 400 MM



POKER



FRONT INOX TABLE 40 CM

**ACCESSORIES**

REF.	DESCRIPTION
759.012	Modular chimney kit 210 mm

Mandatory External firebreak. Info pag 42/43

901.120	Grooved Grill 120 (990x585)
965.120	Skewers Support 120 (capacity 15 u.)
965.021	Chicken Skewers Support 120 (capacity 5 u.)
961.120	1/2 Pizza Baking Sheet 120 (520x590)
970.120	Split 120 4 guias
970.122	Split 120 5 guias
900.122	1/2 Rod Grill 120 (535x625)
901.122	1/2 Grooved Grill 120 (460x585)
960.122	1/2 Griddle Plate 120 (458x590)
965.122	1/2 Skewers Support 120 (capacity 6u.)
955.090	Skewers 90/120
955.120	Chicken Skewers 90/120
950.005	Meat Tongs 330 mm
920.120	Warming Tray 120
924.120	Warming Tray 120 ED
902.912	Front Inox Table 29 cm 120 ED
770.220	Coal Bunker Table Pira 120
770.320	Coal Bunker Table Pira 120 SILVER



GROOVED GRILL



GRIDDLE PLATE



SKEWERS SUPPORT




CHICKEN SKEWERS SUPPORT



WARMING TRAY



SPLIT 120 (4 GUIAS)

COAL BUNKER TABLE PIRA
120 LUXCOAL BUNKER TABLE PIRA
120 SILVER

Алматы (7273)495-231
Ангарск (3955)60-70-56
Архангельск (8182)63-90-72
Астрахань (8512)99-46-04
Барнаул (3852)73-04-60
Белгород (4722)40-23-64
Благовещенск (4162)22-76-07
Брянск (4832)59-03-52
Владивосток (423)249-28-31
Владикавказ (8672)28-90-48
Владимир (4922)49-43-18
Волгоград (844)278-03-48
Вологда (8172)26-41-59
Воронеж (473)204-51-73
Екатеринбург (343)384-55-89

Иваново (4932)77-34-06
Ижевск (3412)26-03-58
Иркутск (395)279-98-46
Казань (843)206-01-48
Калининград (4012)72-03-81
Калуга (4842)92-23-67
Кемерово (3842)65-04-62
Киров (8332)68-02-04
Коломна (4966)23-41-49
Кострома (4942)77-07-48
Краснодар (861)203-40-90
Красноярск (391)204-63-61
Курск (4712)77-13-04
Курган (3522)50-90-47
Липецк (4742)52-20-81

Магнитогорск (3519)55-03-13
Москва (495)268-04-70
Мурманск (8152)59-64-93
Набережные Челны (8552)20-53-41
Нижегород (831)429-08-12
Новокузнецк (3843)20-46-81
Ноябрьск (3496)41-32-12
Новосибирск (383)227-86-73
Омск (3812)21-46-40
Орел (4862)44-53-42
Оренбург (3532)37-68-04
Пенза (8412)22-31-16
Петрозаводск (8142)55-98-37
Псков (8112)59-10-37
Пермь (342)205-81-47

Ростов-на-Дону (863)308-18-15
Рязань (4912)46-61-64
Самара (846)206-03-16
Санкт-Петербург (812)309-46-40
Саратов (845)249-38-78
Севастополь (8692)22-31-93
Саранск (8342)22-96-24
Симферополь (3652)67-13-56
Смоленск (4812)29-41-54
Сочи (862)225-72-31
Ставрополь (8652)20-65-13
Сургут (3462)77-98-35
Сыктывкар (8212)25-95-17
Тамбов (4752)50-40-97
Тверь (4822)63-31-35

Тольятти (8482)63-91-07
Томск (3822)98-41-53
Тула (4872)33-79-87
Тюмень (3452)66-21-18
Ульяновск (8422)24-23-59
Улан-Удэ (3012)59-97-51
Уфа (347)229-48-12
Хабаровск (4212)92-98-04
Чебоксары (8352)28-53-07
Челябинск (351)202-03-61
Череповец (8202)49-02-64
Чита (3022)38-34-83
Якутск (4112)23-90-97
Ярославль (4852)69-52-93

Россия +7(495)268-04-70

Казахстан +7(7172)727-132

Киргизия +996(312)96-26-47

<https://pira.nt-rt.ru> || par@nt-rt.ru